

# Installation Guideline for Tensar TriAx<sup>®</sup> Geogrid for Stabilisation of Granular Fill Over Weak Subgrades

This Installation Guideline provides a step by step guide for Contractors installing Tensar TriAx<sup>®</sup> geogrid supplied by Tensar International or any of its appointed distributors.

The guideline applies to both the permanent and temporary mechanical stabilisation of areas over which vehicular access is to be provided.

Specifications for Tensar geogrids are available on request from Tensar International or a local Tensar Distributor.

## Installation

### Subgrade Preparation

For a subgrade over which construction plant cannot safely traverse:

Tensar TriAx geogrid shall be laid directly on the site, having removed major protrusions such as rocks and tree and bush stumps and also having filled local hollows and depressions with the approved fill but otherwise retaining the vegetation and topsoil covering the site.

or where site conditions permit:

The subgrade shall be levelled in accordance with UK Highway Agency, Manual of Contract Documents for Highway Works (MCDHW), Specification for Highway Works, Clause 616, or as specified in the Contract Documents.

### Placing Tensar TriAx Geogrid

Heavy duty gloves should be worn when handling Tensar TriAx geogrid.

Tensar TriAx geogrid may be placed on the subgrade either parallel to the road centre line or in the transverse direction. If a geotextile separator has also been specified to accompany the TriAx geogrid, then the TriAx geogrid must be placed above the geotextile (so that the placed fill can interlock with the apertures of the TriAx geogrid).

### Overlaps

The width of overlap between adjacent TriAx geogrid lengths is dependent upon the grading and thickness of fill and the stiffness of the subgrade. The minimum overlap shall be 300mm and the maximum normally required shall be 600mm or as directed within the Contract Documents.

Overlaps must be secured and maintained during the filling operation. This is generally achieved by placing small heaps of granular fill locally over the overlaps ahead of the main filling operation.

### Granular Fill

A graded aggregate fill is suitable for the unbound granular fill. Type 1 or 2 is recommended, as described in UK Manual of Contract Documents for Highway Works (MCDHW) Volume 1 Specification for Highway Works, Series 800, clauses 803 and 804 respectively, or as specified in the Contract Documents.

Specifiers are requested to contact Tensar International or a local Tensar Distributor for specific advice when fill other than the above is to be used. A range of Tensar TriAx geogrids is available with different aperture sizes to provide compatibility between aggregate and geogrid ensuring effective interlock.

BS sieve size mm	Percentage by mass passing	
	Sub-base Type 1	Sub-base Type 2
75	100	100
31.5	75-99	75-99
16	43-81	50-90
8	23-66	30-75
4	12-53	15-60
2	6-42	
1	3-32	0-35
0.063	0-9	0-9
	The size fraction of the unbound mixture passing the 0.425 mm size test sieve shall be non-plastic as defined by BS 1377-2 and tested in compliance therewith	The size fraction of the unbound mixture passing the 0.425 mm size test sieve when tested in compliance with BS 1377-2 shall have a plasticity index of less than 6

**Table 1 Subbase Type 1 and Type 2**  
**UK Manual of Contract Documents for Highway Works (MCDHW) Volume 1 Series 800**

**Placing Granular Fill**

Lorry loads of granular fill material shall be tipped into stockpiles on placed fill and not tipped directly onto the TriAx geogrid. The fill stockpiles shall be spread by mechanical plant which causes the aggregate to cascade onto the TriAx geogrid, such as an excavator bucket or dozer with an opening bucket.

Fill shall be spread in layers of not less than 150mm thickness. The initial layer thickness to be placed on the TriAx geogrid shall be specified in the contract documents along with the maximum layer thickness.

In the stabilisation of wide and broad areas, fill shall be spread such that the first layer advances across roll widths rather than along roll lengths.

Care shall be taken to avoid damage to the TriAx geogrid. No traffic or site plant shall be permitted to travel on the TriAx geogrid prior to covering them with a minimum 150mm layer of granular fill.

**Compaction**

Compaction of granular sub-base shall normally be carried out in accordance with UK Manual of Contract Documents for Highway Works (MCDHW) Volume 1 Specification for Highway works, Series 800, or as specified in the Contract Documents. Compaction of other fills shall be carried out in accordance with (MCDHW) Volume 1 Specification for Highway works, Series 600, or as specified in the Contract Documents.

Over exceptionally soft subgrade the degree of compaction applied to the lowest layer of fill may have to be reduced from standard requirements. Details shall be specified within the Contract Documents.

**Contact Tensar International for specific advice.**

This document was formerly published with the reference: CS\_TriAx

The information in this document supersedes any and all prior Installation Guideline for the products/system designated above and is supplied by Tensar International Limited without charge. Tensar International Limited excludes to the fullest extent lawfully permitted any and all liability whatsoever for any loss or damage howsoever arising out of the use of and reliance upon this information. It is your sole responsibility and you must assume all risk and liability for the final determination as to the suitability of any Tensar International Limited product and/or design for the use and in the manner contemplated by you in connection with a particular project.

Tensar and TriAx are registered trademarks

Copyright © Tensar International Limited 2020

**Tensar International Limited**  
Tel: **+44 (0) 1254 262431**  
Fax: **+44 (0) 1254 266867**  
E-mail: **sales@tensar.co.uk**  
**www.tensar-international.com**

**UK Head Office**  
**Units 2 - 4 Cunningham Court**  
**Shadsworth Business Park**  
**Blackburn**  
**BB1 2QX**  
**United Kingdom**



Cert - QMS05288  
Applicable to Tensar International  
and Tensar Manufacturing Ltd



Cert - EMS86463  
Applicable to Tensar Manufacturing Ltd